

TUBE MOP DOUBLE BUCKET

BIOCLEAN ALL-SURFACE



INSTRUCTIONS



STEP 1

Place side-press wringer over grey flushing bucket.



STEP 2

Fill blue bucket to desired level with properly diluted cleaning solution.



STEP 3

Place tube mop in claw handle. Tighten securely.



STEP 4

Place mop in grey flushing bucket. Add enough clear water to cover mop.



STEP 5

Remove wet mop from grey flushing bucket and wring. Over-wringing is not necessary.



STEP 6

Submerge mop in cleaner solution.



STEP 7

Place mop in wringer and wring lightly to prevent dripping.



STEP 8

Clean floor; when mop becomes loaded with soil or dry, place soiled mop in grey flushing bucket and agitate to loosen soil. Wring mop until clean, then repeat steps 5-8 until area is clean.